



## HEATIT EXTERNAL ROOM SENSOR BLACK MATT

External room sensor NTC 10kΩ

**Art.no** 5430133

**GTIN** 7071236016519

Heatit External Room Sensor is designed for use with Multireg and Heatit thermostats. The sensor can be mounted directly on a wall or on top of a standard European wall box. It can be used with most frames that are adapted to System 55. The product comes in a matt version.

When used with a thermostat, dimmer or other products that emit heat, it is recommended that the sensor be mounted below these other products.

It is not possible to connect the sensors in series or in parallel.

### PRODUCT FEATURES

External sensor  
 Designed for use with Multireg- and Heatit thermostats  
 Fits into combination frames  
 Can be mounted directly on the wall or on top of a wall box  
 Connected by cable to the thermostat  
 For indoor use



## MAINTENANCE

The device is maintenance-free. Indoor use only.

## ADDITIONAL INFORMATION

Cross-section cable: Ø1.5mm<sup>2</sup>

## PRODUCT INFO RETURN AND RECYCLING

The product must be recycled as electronic waste.

## STANDARDS

Certification	Reach RoHS	EN Standards	CE
IP Code	IP21		

## WARRANTY

Warranty Norway	5 years	Warranty international	2 years
-----------------	---------	------------------------	---------

## LOGISTICAL DATA (F-PACK)

Width	88mm	Height/diameter	25mm
Length	88mm	Weight	81g
GTIN	7071236016519	Unit	BOX
Consists of unit	EA	Quantity	1

## LOGISTICAL DATA (M-PACK)

Width	273mm	Height/diameter	190mm
Length	370mm	Weight	6400g
GTIN	-	Unit	CARTON
Consists of unit	BOX	Quantity	80

## LOGISTICAL DATA (D-PACK)

Width	383mm	Height/diameter	210mm
Length	565mm	Weight	13500g
GTIN	-	Unit	CARTON
Consists of unit	CARTON	Quantity	160



## DISCLAIMER


We develop and design our products according in accordance with our strict quality requirements (ISO 9001) and environmental requirements (ISO 14001).

All electrical installations must be carried out by an authorized electrical installer. The product must be installed in accordance with our installers manual and national building codes. Any wrongful installation, misuse, damage of the product, is not covered under warranty.

Updated documentation is available at [www.heatit.com](http://www.heatit.com) and/or [documents.heatit.com](http://documents.heatit.com)

Heatit Controls AB can not be held liable for any type of errors or omissions in our product information.

Product specifications may change without further notice.



**Heatit External Room Sensor Black Matt can be ordered from**  
**[www.heatit.com/5430133](http://www.heatit.com/5430133)**

All additional documentation are available on the above adress and on [documents.heatit.com/5430133](http://documents.heatit.com/5430133)

